

1/4

FIG. 1







3/4

FIG. 3

300

FREQUENCY INTERLEAVER ENTRY MATRIX							
	COL 0	COL 1	COL 2	• • •	COL 29	COL 30	COL 31
ROW 0	IO	I1	I2		I29	· I30	I31
ROW 1	I32	I33	I34		I61	I62	I63
ROW 2	I64	I65	I66		I93	I94	195
•	•	•	•		•	:	•
ROW 31	I960	I961	I962		Q13	Q14	Q15
ROW 32	Q16	Q17	Q18		Q45	Q46	Q47
	•	•	•		•	•	•
ROW 59	Q912	Q913	Q914		Q941	Q942	Q943
ROW 60	Q944	Q945	Q946		Q973	Q974	Q975

